

Multi-Rack Package 1

ASSEMBLY INSTRUCTIONS

Rudy Rack

P.O. Box 133
Plover, WI 54467
800-434-6442
www.rudyrack.com

1. Attach 4 PIVOTING CASTERS to the 18" BASE. Place a 3/8" nut on to each caster and tighten in place.
2. Drop the 52" MAST into the fitting on the 18" PLATE. Place two 5/16" x 1/2" bolts into the pre-threaded holes on the fitting. Tighten the bolts to secure 52" MAST in place.
3. Attach the two TEE ATTACHMENTS to the MAST facing in opposite directions. Tighten each TEE ATTACHMENT to the MAST by using the provided 1/4" x 1 1/2" bolts and 1/4" nuts
4. A variety of black plastic end-caps are included. Plug them into the exposed ends of tubing for a finished look.

