

Multi-Rack Package 5

ASSEMBLY INSTRUCTIONS

Rudy Rack

P.O. Box 133

Plover, WI 54467

800-434-6442

www.rudyrack.com

1. Attach 4 PIVOTING CASTERS to the 18" BASE. Place a 3/8" nut on to each caster and tighten in place.
2. Drop the 52" MAST into the fitting on the 18" PLATE. Place two 5/16" x 1/2" bolts into the pre-threaded holes on the fitting. Tighten the bolts to secure 52" MAST in place.
3. Attach the 2 CASCADE ATTACHMENTS to the MAST as pictured. Tighten the CASCADE ATTACHMENTS to the MAST by using the provided 1/4" x 1 1/2" bolts and 1/4" nuts.
4. A variety of black plastic end-caps are included. Plug them into the exposed ends of tubing for a finished look.

