3 Bike Highlighter Parts List





3-Bike Highlighter

1. Insert the floor section into the center legs with the tabs facing up, then insert the 4th tier section into the center legs. Adjust to desired spacing and secure using 5/16" x 1/2" bolts.

 Insert the (2) Single Legs into the other side of the Center Section. Tighten with (2) 5/16" x 1/2" Bolts.

 Insert the Top Section into the (2) Single Legs. The End Trays should be facing the same way. Tighten with (2) 5/16" x 1/2" Bolts at your desired spacing.

 Attach the (3) Stanchions onto the (3) sections using (2) 5/16" x 1/2" Bolts and (2) 5/16" Washers for each Stanchion.

 Insert (1) Tray Catch to the exposed holes in the front of each stanchion. Adjust the catch to the desired wheel base. Tighten using (1) 1/4" x 3/8" Setscrews.

6 Insert the provided 1" and 1/2" Black Plugs into the exposed ends to give the Highlighter a finished look.



