## TIRE TOTTER 4-HOLE







## HARDWARE

SHOULDER BOLTS 5/16-18 X 1/2"

5/16" X 1-1/2" BOLTS

5/16" LOCK NUTS

5/16" WASHERS

BEGIN BY UNPACKING
ALL BOXES AND
LOCATING THE HARDWARE BAG

Step 1: Line up the Cradle and Base holes as shown.

Insert two Shoulder Bolts into the holes and tighten both at the same time.



Step 2: Mount using the provided 5/16" x 1-1/2" Bolts, 5/16" Washers, and 5/16" Lock Nuts.



