




5 Bike Recumbent Parts List




(1) Top Section



(3) Upper Small Tray




(1) High T-Support




(2) Center Section



(1) Rear
Lower
Small Tray




(2) Low T-Support




(1) Front Floor Section



(1) Front
Lower
Small Tray



(4) 36" T Base



(1) Rear Floor Section



(2) Double Legs



(5) 49" Bar

Hardware:


- (24) 5/16" 1/2" Bolts
- (20) 1/2" Black Plugs
- (16) 1" Black Plugs
- (8) Davies Knobs
- (1) Rudy Rack Sticker

Caster Add-On

- (6) Caster Stems
- (2) Casters with Lock
- (8) C-Channel Caster Bracket
- (16) 1/4" x 1 3/4" Bolts
- (16) 1/4" Stopnut

5-Bike Recumbent

1. Lay out (4) 36" T Bases and connect with (2) Double Legs. Tighten using (4) Davies Knobs.
2. Insert the Front Floor Section and Rear Floor Section into the ends of the 36" T-Bases. Tighten using (4) Davies Knobs.
3. Insert Top Tray Section into Double Legs. Place the (2) Center Tray Sections on the (4) 36" T Bases. Tighten using (6) 5/16" x 1/2" Bolts.
4. Insert a 49" Bar into the end of the Top, Center, and Floor Sections. Tighten using (5) 5/16" x 1/2" Bolts.
5. Insert each Lower Small Tray onto the 49" Bars of the Front and Rear Floor Sections. Tighten using (4) 5/16" x 1/2" Bolts.
6. Insert (2) Upper Small Tray on the top of the (2) Low T-Support and slide onto the 49" Bar of Center Tray Sections. Tighten using (6) 5/16" x 1/2" Bolts.
7. Insert Upper Small Tray on top of the High T-Support and slide onto the 49" Bar of Top Tray Section. Tighten using (3) 5/16" x 1/2" Bolts.
8. Insert the provided 1" and 1/2" Black Plugs into the exposed ends to give the Recumbent Rack a finished look.
9. If Casters were purchased simply slide the C-Channel onto 49" Bar, as shown. Tighten each using (1) 1/4" x 1 3/4" Bolts and (2) 1/4" Stopnuts.



Thank you for your purchase with Rudy Rack.