


SUPER HIGHLIGHTER V1.9

3 BIKE




HARDWARE

- | | |
|--------------------------|----------------------|
| (16) 5/16" x 1/2" Bolts | (6) 1/4" Stopnut |
| (6) 1/4" x 3/4" Bolts | (12) 1/4" Washers |
| (6) 5/16" x 3/4" Bolts | (8) 5/16" Washers |
| (2) 5/16" x 1-1/2" Bolts | (12) 1/2" x 1" Plugs |
| (2) 1 1/4" 14GA Plugs | |

TOOLS REQUIRED

- (2) 7/16" WRENCHES
(1) 1/2" WRENCH

A. (3) Stanchion



B. (3) Tray



C. (2) 26.5" Vertical Insert




D. (2) 15.5" Vertical Insert



E. (2) End Leg



F. (2) Center Leg



G. (2) Front Leg



H. (1) Stabilizer Bar




Before rack Assembly, Locate hardware and
Unpack and identify all parts

TRAY ASSEMBLY


step 1

Flip a stanchion and tray upside down. Align the 2 holes in the stanchion with the 2 holes in the tray. The tray should be on the outside of the stanchion, as shown in Dia. 1.



step 2

Place a 1/4" washer over a 1/4" x 3/4" bolt. Insert the assembly through one of the holes, as shown in Dia. 2. Loosely tighten with a 1/4" stopnut and washer.




step 3

Repeat Step #2 in the open hole, as shown in Dia. 3. Tighten using two wrenches.




step 4

Insert 2 of the 1/2" x 1" Plugs in the open holes in the front of the stanchion, as shown in Dia. 4.



step 5

Insert 2 of the plugs in the back of the stanchion, as shown in Dia. 5. Your tray is now complete.




RACK ASSEMBLY

Step One


Locate (1) Front Leg and (1) Center Leg. With the threaded hole on the Front Leg pointing up, insert the Front Leg into the Center Leg, as shown in Diagram 1. The smaller tube on the Center Leg should be facing toward the back of the rack.

The space between the Front and Center Leg will determine how much space is between the bikes. Determine desired spacing and loosely tighten (2) 5/16" x 1/2" Bolts into the weld tabs with fingers.



Step Two

Locate (1) End Leg and slide it onto the Center Leg, as shown in Diagram 2. The short tube on the End Leg should point toward the back of the rack. Loosely tighten (2) 5/16" x 1/2" Bolts on the End Leg in the desired position.



Dia. 2

Step Three


Repeat Steps 1 and 2 two complete the other side of the 3 Bike Highlighter, as shown in Diagram 3.




Dia. 3

Step Four

Attach the (1) Stabilizer Bar to the End Legs using (2) 5/16" x 1-1/2" Bolts and (2) 5/16" Washers as shown in Diagrams 4 and 4B.




Dia. 4



Dia. 4B

Step Five


Locate the (2) 15.5" Vertical Inserts and insert them into the open tube on the Center Legs, with the tapped hole pointing up as shown in Diagram 5. DO NOT SECURE



Dia. 5

Step Six

Locate the (2) 26.5" Vertical Inserts and insert into the open tube on the End Legs, as shown in Diagram 6. DO NOT SECURE




Dia. 6

Step Seven

Now attach the previously assembled trays to the structure. Line up the hole in the Stanchion to the hole on the Left Front Leg and secure using (1) 5/16" Washer and (1) 5/16" x 3/4" Bolt.


Attach the end of the Tray to the Right Front Leg using (1) 5/16" Washer and (1) 5/16" x 3/4" Bolt, as shown in Diagram 7.



Dia. 7

Note: there are two drilled holes on the tray. Use the hole that is closest to the end of the tray.





Step Eight

Adjust the height of each tray to your desired setting and secure in place using (4) 5/16" x 1/2" Bolts.

Go back through the rack and tighten any loose bolts and install the (2) 1 1/4" 14GA plugs in the bottom rear of rack

Note: the rack can be set at any angle - even straight! To adjust the angle, just loosen the bolts that attach the trays to the structure, change the angle, and re-secure.


For Highlighters with Casters, move on to the next section.



CASTERS KIT

HARDWARE

- (4)-1/4" x 1 3/4" Bolts
- (4)-1/4" Stop Nuts



To attach casters, follow steps 1 - 8 to assemble the rack.

Locate (2) C-Channels and slide onto the End Legs as shown in Diagram 2. Secure in place with (1) 1/4" x 1 3/4" Bolt and (1) 1/4" Stopnut each.

Attach the remaining (2) C-Channels to the Front Legs and secure in place with (1) 1/4" x 1 3/4" Bolt and (1) 1/4" Stopnut each.

