




DELUXE ADJUSTABLE SPACE SAVER - PARTS

HARDWARE

3 - 1/4" x 3/8" SET
SCREWS PER SIDE FRAME.
(6 PER SPACE SAVER)



GENERAL SUGGESTED SPACING



RUNNER LENGTH (A)

END OF RUNNER TO
CENTER OF SPACE SAVER* (B)

CENTER OF SPACE SAVER TO
CENTER OF SPACE SAVER* (C)

107 1/2"

6 3/4"

13 1/2"

89"

6 3/8"

12 3/4"

74 1/2"

6 3/16"

12 3/8"

60"

6"

12"

45 1/2"

5 11/16"

11 3/8"


31"

5 1/8"

10 5/16"


* APPROXIMATE LENGTHS, MAY HAVE BEEN ROUNDED.

DELUXE ADJUSTABLE SPACE SAVER - ASSEMBLY INSTRUCTIONS





1.
LOCATE THE RUNNERS (3). TAKE TWO OF THEM AND LAY THEM OUT ON THE FLOOR WITH ROUGHLY 18" BETWEEN THEM, AS SHOWN IN THE DIAGRAM TO THE LEFT.

2.
NEXT TAKE ONE OF THE SIDE FRAMES AND SLIDE IT ONTO THE RUNNERS (THROUGH THE BOTTOM TWO TUBES). SLIDE THE SIDE FRAME ABOUT 16" - 20" DOWN FROM THE END AND SECURE TO THE RUNNERS USING 5/16" x 3/8" SET SCREWS, AS SHOWN IN THE DIAGRAM TO THE RIGHT.



3.
TAKE THE REMAINING SIDE FRAMES AND SLIDE THEM ONTO THE RUNNERS LIKE YOU DID IN STEP 2. "STACKING" THEM AT THE END OF THE RUNNERS, AS SHOWN IN THE DIAGRAM TO THE LEFT. DO NOT SECURE IN PLACE.

4.
NOW TAKE THE LAST RUNNER AND SLIDE THROUGH THE TUBES ON TOP OF THE SIDE FRAMES, AS SHOWN IN THE DIAGRAM TO THE RIGHT.



5.
ONCE THE TOP RUNNER IS INSERTED THROUGH ALL OF THE SIDE FRAMES IT IS TIME TO "SET" THE END SIDE FRAME. LOOSEN THE PREVIOUSLY SECURED SIDE FRAME SET SCREWS. NOW DETERMINE HOW FAR FROM THE END YOU WOULD LIKE YOUR FIRST SPACE SAVER TO BE AND SLIDE THE RUNNERS OUT UNTIL ALL THREE HAVE THE SAME AMOUNT OF OVERHANG OFF OF ONE SIDE. SECURE THAT SIDE FRAME (ONLY THE END SIDE FRAME) TO THE RUNNERS (ALL 3) USING 5/16" x 3/8" SET SCREWS. AS SHOWN IN THE DIAGRAM TO THE LEFT.

6.
THE NEXT STEP IS TO SET THE REST OF THE SIDE FRAMES IN PLACE WORKING FROM ONE END (THE END WITH THE SIDE FRAME SECURED DOWN TO THE RUNNER) TO THE OTHER END.
SLIDE ALL THE FRAMES AS ONE TO AVOID BINDING ON THE RUNNERS. SETTING THE 2ND SIDE FRAME TO THE DESIRED WIDTH OF THE SPACE SAVER (WIDTH OF TIRE IT WILL BE HOLDING). THEN THE THIRD SIDE FRAME SETS THE GAP BETWEEN THE FIRST AND SECOND SPACE SAVER, FOLLOWED BY THE FOURTH SIDE FRAME SETS THE WIDTH OF THE SECOND SPACE SAVER... AND SO ON AS YOU GO DOWN THE LENGTH OF THE RUNNERS. (SEE PARTS PAGE FOR ROUGH SPACING GUIDELINES), AS SHOWN IN THE DIAGRAM TO THE RIGHT.



7.
ONCE YOU HAVE YOUR SIDE FRAMES IN THEIR DESIRED LOCATIONS GO BACK AND SECURELY TIGHTEN ALL OF THE SIDE FRAMES TO THE RUNNERS USING 5/16" x 3/8" SET SCREWS.
YOUR ADJUSTABLE SPACE SAVER DELUXE ASSEMBLY SHOULD NOW BE COMPLETE AND SOMEWHAT RESEMBLE THE DIAGRAM TO THE LEFT.